



Isobella Wall Light, Us

£125

Regular

£106

Membership

Product details

The Isobella wall light is inspired by the traditional interiors at Babington House. Paired with an ivory mushroom-pleated cotton shade, the light is constructed from blackened brass with refined stem and arm details. A great addition to a hallway, bedroom or office.

- Blackened brass wall light
- Refined stem and arm details
- Ivory cotton pleated shade
- Requires 1 x Standard E12 bulb/ max 28W
- Inspired by Babington House

Dimensions

Product dimensions: H39 x W14 x D20cm / H15.4 x W5.5 x D7.9"

Product weight: 1kg / 2.2lbs

Packaged or boxed dimensions: H45 x W45 x D39cm / H17.7 x W17.7 x D15.4"

Packaged or boxed weight: 6kg / 13.2lbs

Details

Assembly required: Yes, specialist

Bulb required: 1 / E12 / 4W Maximum

Bulb style: Tala 4W Sphere I LED

Bulb(s) included: No

Care instructions: Clean with a soft dry cloth only. Do not use polishing agents, harsh chemicals or abrasive cleaners as they may damage the finish.

Always switch off the electricity supply before cleaning.

Dimmable: Yes, please consult a qualified

Electrician required: Yes

Height adjustable: No

Voltage: 110-120V


Wall bracket: 4.7



SOHO HOUSE




SOHO HOUSE



CLASSIC WALL LIGHT

74542928

PARTS LIST



- (A) Wall light (x1)
- (B) Mounting bracket (x1)(attached on wall plate)
- (C) Terminal block (x1)
- (D) Lamp holder ring(x1)
- (E) Shade(x1)

PRODUCT DIMENSION

390H x 140W x 200D mm(15.4H x 5.5W x 7.9D inch)

IMPORTANT SAFETY INSTRUCTIONS

- These instructions are provided for your safety.
- Please read instructions carefully and completely before beginning the assembly and installation of this lighting fixture.
- This fixture has been rated for up to one (1) E14 28Watt Maximum light bulb (not included). To avoid the risk of fire, do not exceed the recommended lamp wattage. Dispose of old bulbs with care.
- For your safety: if the external flexible cable becomes damaged, it must be exclusively replaced by a qualified person in order to avoid any danger or the lighting fixture must be discarded.
- Unless otherwise marked / illustrated this lamp is meant for use in a dry, domestic, indoor environment only.
- The finish is only guaranteed against normal non-aggressive atmospheric conditions.
- Do not fit in locations near a heat source, the sea, or in polluted atmospheres.
- Please retain these instructions for future reference. If the product is sold please ensure the instructions are left with the appliance for the benefit and safety of the new owner.

If you need help or have damaged or missing parts, our team is here to assist.

Please email hello@sohohome.com or call +44 (0)20 3819 8199



This light fixture is classified
as Class I(Earthed)

WARNING

- Electricity can be dangerous.
- Disconnect the power supply at the fuse box before installation.
- Installation must be carried out by a competent person.
- If in any doubt consult a qualified electrician.
- Installation must comply with current local and national wiring regulations.

CHILD SAFETY

- Do not allow children to tamper with the product.
- Keep packaging out of reach of children.

INSTALLATION

- Take care when handling and installing to avoid damage to the product.
- Remove all parts and hardware from box along with any plastic protective packaging.
- Do not discard any contents until after assembly is complete to avoid accidentally discarding small parts or hardware.
- Avoid mounting the fitting on a damp surface such as newly painted or plastered area. This may cause discoloration of the finish.
- When installing and whenever acting on the appliance ensure that the power supply has been switched off.


CARE INSTRUCTIONS

- Wipe clean with a soft, dry cloth or static duster only.
- Always avoid the use of polishing agents, water, harsh chemicals or abrasive materials when cleaning as they may cause damage to the fixture.
- Always switch off the electricity supply before cleaning.

TOOLS REQUIRED (Not Supplied)


- Cross Head Screwdriver
- Flat Head Screwdriver
- Pencil
- Drill
- Insulation Tape

1




Remove the fixing screws and mounting bracket (B) from wall plate and retain for later use.

2




Using the bracket (B) as a template, mark and drill fixing holes on the wall.
Due to the variety of different ceiling types Soho Home cannot provide you with the exact fittings needed to fix this product to the wall. Different materials require different types of fittings.

3




Attach the bracket (B) onto the wall using suitable fittings.
You will need to choose fittings that are specifically suited to the ceiling type and material you have. If you are unsure about what type of fittings to use please consult your local hardware store and/or qualified tradesperson to get the appropriate fittings.

4




Connect the supply wires to the terminal block (C), opposite the corresponding wires from the fitting. Ensure that connections are tight and no loose strands of wire are left out of the connector block.

5



Use the fixing screws provided to secure the fitting to the pre fixed bracket (B) ensuring that the fixing points can bear the total weight of the fitting.


6



1. Unscrew lamp holder ring (D) from the lampholder.
2. Place the shade (E) onto the lampholder.
3. Secure the shade (E) in place by turning the lamp holder ring (D) in a clockwise direction until tight.

7

Bulb not included



Insert the specified light bulb into the Lampholder.
DO NOT EXCEED THE SPECIFIED WATTAGE.